


KEEP AREA CLEAR FOR SYSTEM MAINTENANCE AND FUELING



SCALE 1"= 20 ft

6" x 20' Bauer Gravity Discharge to River
w/ flow spreader to gravels

NSC WATER QUALITY

PO BOX 2319 REDMOND WA 98073
(425)864-1645 ericnwsolciment@yahoo.com

Process Water Tank Schematic

5-17-12

Avery Landing Site ; Avery, Idaho